



EXTERIOR DIY

HOW TO LAY A CONCRETE PAD

WHAT YOU'LL NEED

TOOLS:

- Boxing timber (100 x 25mm rough sawn untreated timber)
- Nails
- Dazzle
- Base course
- Pegs
- Sand
- Polythene
- Mesh
- Aggregate
- Cement

MATERIALS:

- Hammer
- Compactor
- Rake
- Concrete mixer
- Gloves
- Magnesium (mag) trowel
- Steel trowel
- Shovel
- Straight edge
- Level

